






7. Skip a track by doing a flicking motion.





8. Change between songs by doing a sweeping motion in either a left or right direction.

